### **ARTE**

# Alex Roitman Tango Ensemble Tango Sextet for Theater Shows

#### **Tech Rider**

#### **Equipment and instruments required**

- 1 grand piano.
- 1 adjustable piano bench.
- 1 double bass (¾ size, adjustable bridge, adjustable pin, preferably from a musician).
- 2 chairs without arm rests, sitting height no higher than 18 inches.
- 6 stage monitors, each with independent mix.
- 5 music stands with lights.

#### Mics and stands required

- 8 Neumann KM184 or similar (2 for piano, 2 for each bandoneon, 1 for each violin).
- 8 tall mic stands with telescoping booms (2 for piano, 2 for each bandoneon, 1 for each violin).
- 1 vocal mic for the vocalist.
- 1 mic stand for the vocalist.
- 1 available XLR line with 48V power for a clip-on bass mic that we bring

#### Piano requirements

One concert grand piano in excellent condition (9 foot Steinway Concert D preferred), with padded, adjustable artist bench is required. The piano must be placed on stage and tuned to A-442 on the day of the performance.

#### **Input list**

- Piano:
  - Left: Channel 1
  - o Right: Channel 2
  - o 2 tall booms
  - o 2 Neumann KM184 or similar
- Double bass:
  - Mic on a stand: Channel 3
  - ∘ Clip-on mic (we bring it): Channel 4
  - o 1 Short Boom
  - 1 AKG414 or similar (stand mic)
- Violin 1:
  - o Channel 5
  - 1 Neumann KM184 or similar
  - o 1 Tall Boom
- Violin 2:
  - o Channel 6
  - 1 Neumann KM184 or similar
  - o 1 Tall Boom
- Bandoneon 1:
  - o Left: Channel 7
  - o Right: Channel 8
  - o 2 Tall Booms
  - o 2 Neumann KM184 or similar
- Bandoneon 2:
  - o Left: Channel 9
  - Right: Channel 10
  - o 2 Tall Booms
  - o 2 Neumann KM184 or similar
- Vocalist:
  - 1 vocal mic with stand: Channel 11

## Input table

Channel	Instrument	Mic Stand	Mic
1, 2	Piano (Left) Channel 1 Piano (Right) Channel 2	2 tall booms	2 Neumann KM184 or similar
3, 4	Double Bass Mic: Channel 3 Clip-on: Channel 4	1 short boom	1 AKG 414 or similar we bring clip-on mic
5	Violin 1	1 tall boom	1 Neumann KM184 or similar
6	Violin 2	1 tall boom	1 Neumann KM184 or similar
7, 8	Bandoneon 1 (Left) Channel 7 Bandoneon 1 (Right) Channel 8	2 tall booms	2 Neumann KM184 or similar
9, 10	Bandoneon 2 (Left) Channel 9 Bandoneon 2 (Right) Channel 10	2 tall booms	2 Neumann KM184 or similar
11	Vocalist	1 vocal mic stand	1 vocal mic